

FITTING INSTRUCTIONS



Pack includes

Heavy duty custom spring base 1.07m Fiberglass pole (full antenna height, with base: 1.21m) Includes grub screw and hex key to secure the fiberglass pole

IMPORTANT - Always fit in accordance with State Road & Traffic Safety Guidelines

Installation

- 1. Remove the shroud protecting the cable at the base of the antenna.
- 2. Install the spring base onto the bracket (not supplied). Tigten in a clockwise direction using a hexagon wrench or spanner. IMPORTANT: Do not exceed 50N.





3. Remove the cap from the top of the spring base and install the fiberglass extension pole on to the base by turning in a clockwise direction and secure in palce with the grub screw (using the hex key provied). Hand tighten only MAX. 15N.

