




**Enerdrive**  
DRIVING YOUR ENERGY NEEDS

**In Vehicle & Marine Applications**  
For In Vehicle & Marine Installations.  
i.e. Motorhomes, 4WD's, Trucks & Boats

**Please NOTE:**

Vehicles with a Smart alternator, the Negative cable must be connected to the vehicle Side of the Battery Sense Module.

Non Regulated Fix or Folding Solar Panels Max 45VOC  
See Manual for input specifications



**DC to DC Battery Charger**



(Optional)  
Ignition sense wire  
required for smart  
alternator vehicles




Fuse  
1Amp

See Owners  
Manual for  
cable size


Ignition Link  
1.5mm<sup>2</sup>

(Optional)  
Solar  
Isolator

**DC Loads**



See Owners  
Manual for  
cable size



**12v House Battery**

Enerdrive has provided this drawing as a guide only and installers must ensure the system is installed to the local requirements for fuse protection and wire sizing (see Manual).  
If you have any questions please call:  
Enerdrive on 07 3390 6900




**Enerdrive**  
DRIVING YOUR ENERGY NEEDS

**Towed Applications**  
For Towed Installations.  
i.e. Caravans & Camper Trailers

**Please NOTE:**  
Vehicles with a Smart alternator, the Negative cable must be connected to the vehicle Side of the Battery Sense Module.

Non Regulated Fix or Folding Solar Panels Max 45VOC  
See Manual for input specifications



Enerdrive has provided this drawing as a guide only and installers must ensure the system is installed to the local requirements for fuse protection and wire sizing (see Manual).  
If you have any questions please call:  
Enerdrive on 07 3390 6900

12v House Battery